



BROWN & GAMMONS LTD

SUN MATE

BGF401

This exclusive product is designed to extend the life of your hood and protect your interior.

To fit, simply open your boot, pull through the back edge of the 'Sunmate' ensuring the neoprene cord is laid in the boot gutter and close the lid. Pull the front elastics over the mirror housings and press the two suction cups on the side onto each door glass pulling tight over the centre of the car and the two suction cups on the front screen trapping the 'Sunmate' under the window wipers.



Brown & Gammons Ltd, 18 High Street, Baldock, Herts, SG7 6AS.
Tel: 01462 490049 sales@ukmgparts.com